


Číslo typu FS2700 SCREW DRIVER



Položka	Číslo dílu	Popis	Změn	Množstv	N/O	Možnost 1	Možnost 2	Poznámka
001	322120-3	doraz 10		1				
002	213310-8	o-kroužek 20		1				
003	322073-6	držák dorazu		1				
004	231940-3	zajišťovací pružina 22		1				
005	168552-8	skříň spojky		1				
C10	313166-0	BRAKE RING		1				
007	213343-3	o kroužek FS2700=old213486-1		1				
008	253806-7	podložka 36		1				
009	152841-1	kroužek		1				
010	216001-0	kulička 3,5		1				
011	325606-6	vřeteno		1				
012	234095-3	přížina		1				
013	232050-9	listová pružina		1				
014	216008-6	kulička 4		1				
015	233314-4	pružina aretace momentu 6827		1				
016	268075-7	čep 6827		1				
017	318387-9	GEAR HOUSING TC		1				
018	266361-0	šroubek 4x30		3				
019	268075-7	čep 6827		1				
021	442149-4	GASKET		1				
022	158982-1	GEAR HOUSING COVER COMPLETE		1				
023	451099-2	kroužek		1				
024	210007-0	kuličkové ložisko 608VV		1				
025	240083-0	větrák		1				
026	515764-8	ARMATURE ASSEMBLY 240V		1				
D10		INC. 23-25,27,28						
027	681636-0	izolační podložka = old 681667-9		1				
028	210062-2	ložisko MT952		1				
029	421868-5	kroužek 9554-9555		1				
030	266467-4	TAPPING SCREW 4X50		2				
031	450880-8	BAFFLE PLATE		1				
032	633693-4	stator		1				
033	450878-5	MOTOR HOUSING L		1				
034	162272-6	HOOK		1				
035	867048-3	FS2700 NAME PLATE		1				
036	808574-3	INDICATION LABEL		1				
037	689111-0	guma držáku uhlíků HR2440		2				
038	191962-4	uhlíky CB-419 = CB-406,407		1				
039	643952-8	BRUSH HOLDER		1				
040	643953-6	BRUSH HOLDER		1				
041	687124-5	držák kabelu		1				
042	650614-1	vypínač		1				
043	158878-6	držadlo		1				
C10	263002-9	vymezovací čep 4		2				
044	266374-1	šroub 4x25		1				
045	266374-1	šroub 4x25		2				
046	631939-2	LIGHT CIRCUIT		1				
047	646122-8	kondenzátor=old645253-0		1				

